

How to run an automatic dishwasher

# **BEFORE** LOADING










### LOADING

Load maximum capacity.

Place items in correct position for good contact with water.

Make sure cutlery doesn't stick out of the bottom of basket.



Make sure no dish is covered by larger items.

Put heavily soiled dishes into the lower basket for intensive water treatment.

Face opening of vessels / bowls / cups down.

# USAGE





For lightly soiled dishes, use low temperature wash or light wash cycle.





For heavily soiled dishes, use high temperature wash or pots and pans cycle.





For drying, use low temperature or air dry cycle.

Use the start time delay function if lower utility rates are available at a later day time.

> Dose the detergent and rinse aid as recommended by the appliance and detergent manufacturer.

Choose manufacturer recommended cycle and temperature according to both the type and soil level of dishes.

# WASHING




Switch off the dishwasher directly at cycle end.

Open the door for expelling humid air from the machine.



Check and clean spray arms and filter regularly.



**PURCHASING** A NEW MODEL



Look for appliances that use less water & energy



Choose a load capacity that fits your needs



Make sure it has an internal electric heater for the water



Permission is granted to copy the "Best Practice Tips" free of charge as long as they are used complete and unchanged, although credit is requested to IFHE (PC Household Technology & Sustainability). If modifications are intended, permission may be requested at office@ifhe.org. To download our full Best Practice Posters, please visit the "Best Practice" section at www.ifhe.org.



