


MACHINE LAUNDERING



How to run a laundry machine

BEST PRACTICE TIPS



1 BEFORE WASHING

Sort your laundry into relevant wash loads. (whites, colors, delicates)



Remove accessories from your clothes.


Turn the clothing inside out; pre-treating stains if necessary.



Every day, large amounts of water & energy are wasted due to unnecessary laundry washing. Help save resources by avoiding unnecessary laundry washing!


2 WASHING

Load the washing machine to the indicated capacity. Note the load capacity for delicates and wool may differ.



Check the detergent's label for proper dosing.

Dose detergent according to soil level and water hardness.



Extra-large Load

Fill the laundry almost full, but make sure clothes can tumble freely.




Large Load

Fill the laundry up to about 3/4 full.




Medium Load

Fill the laundry up to about 1/2 full.



Choose washing and temperature settings according to textile care instructions and soil levels.



Do not use over 60 °C for whites and colors.

40 °C or lower is sufficient. Select as low temperature as possible.


3 AFTER WASHING



Use the highest spin setting when drying in a tumbler.

Remove and dry the laundry immediately after the wash cycle is complete.

Always leave the detergent drawer open after use



To sanitize your washing machine, wash once per month at 60 °C; using a combination of bleach and detergent.



IFHE
INTERNATIONAL FEDERATION
FOR HOME ECONOMICS

Permission is granted to copy the "Best Practice Tips" free of charge as long as they are used complete and unchanged, although credit is requested to IFHE (PC Household Technology & Sustainability). If modifications are intended, permission may be requested at office@ifhe.org. To download our full Best Practice Posters, please visit the "Best Practice" section at www.ifhe.org.

IFHE www.ifhe.org office@ifhe.org

